



# CONNECTED HOME




Smart WiFi Window/Door Sensor  
MANUAL  
XHS7-2001-WHT

# GETTING STARTED

Thank you for choosing the **Xtreme™ Connected Home** Window/Door Sensor. This quick start guide will help you with setup and installation.

## Package Includes:

ESTIMATED SETUP



- Smart Window/Door Sensor
- Quick Start Guide

## What You Need:



**App**



2.4GHz



5GHz



**2.4GHz WiFi**





Before setup, make sure your phone is connected to the 2.4GHz WiFi network that your device will be placed on. You may also need to turn on location and Bluetooth to find nearby networks.



# CONNECT THE DEVICE

## STEP 1

Download the free **Xtreme™ Connected Home** app from the App Store (for iPhones) or Google Play Store (for Android phones).




## STEP 2

Make sure your mobile device is connected to your **2.4GHz WiFi** network.

Open the app and **click** "Register" by following the on-screen instructions.

After your initial sign in, your app will remember your password and log you in automatically.


You can also choose to manually log out under Settings in the Main menu.



**Click**

Register

Log in with existing account



You may need to check your Spam folder for the verification code

## STEP 3

Remove back cover by pressing the button on top of the sensor and pulling back on the cover. Power with 2 AAA batteries (not included).



The indicator light on the sensor should start blinking **RED** for pairing mode.

LED Behavior		Device Status
Red	Blinking	Pairing Mode
	Solid	Starting Up
Blue	Blinking	Attempting to Pair
	Solid	Connected

If the LED is not blinking, then you are not in pairing mode. Reset the sensor by **pressing** the reset button for 5 seconds until you hear the camera make a chime sound.

**Press**  
Reset  
button



## STEP 4

After logging in, **click** "+" on the top right of the screen and **select** "Add device".



**Click**



**Select**



## STEP 5

Select Sensor category and **confirm** the indicator light is still rapidly blinking. **Click** "Confirm indicator rapidly blink".



**?** **Help:** Switch between pairing modes. See troubleshooting page 8.




## STEP 6

**Confirm** that the displayed **WiFi** network is your **2.4GHz WiFi** network, **enter** your WiFi password and **click** "Confirm".

### Confirm WiFi




### Enter and Click




**?** **Help:** If you need information about **2.4GHz WiFi** networks, click the link to go to our Connect FAQs on our website.

# STEP 7

Your Smart Window/Door Sensor will now be connected to the network. Confirm the settings for your device and then **Click** “Done”.

**TIP:** You can put your camera directly in a room by selecting one of the available rooms. **Click** the  button to change the name of the product.

PROCESSING TIME



Your **Xtreme™ Connected Home** Smart Door/Window Sensor is now ready to use. You can now view the sensor remotely and receive mobile alerts. We hope you enjoy using your **Xtreme™ Connected Home** Smart Door/Window Sensor. For frequently asked questions and instruction videos, please visit our website at [www.xtremeconnected.com](http://www.xtremeconnected.com).

# INSTALLATION

1. Insert 2 AAA batteries (not included).



1. Install the sensor in desired location with double sided mounting tape.





To see Warranty information and Certification Legal warnings, please see our website.

**[www.xtremeconnected.com](http://www.xtremeconnected.com)**

Message and Data rates may apply. If you have any questions about this product contact the manufacturer for support, do not return to retailer.

Referenced brands and trademarks are for compatibility listing only, not associated with this product. iPhone is a trademark of Apple INC., registered in the US and other countries.

App store is a service mark of Apple Inc. Google Play and Google Play logo are trademarks of Google Inc. © 2022 Google Inc. All rights reserved.

Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

## **FCC Compliance**

This device complies with Part 15 of the FCC. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## HAVING TROUBLE WITH SETUP?

**Don't return this product to the retailer, we're here to help.**

Please call us at **855-999-8041** or visit **[www.xtremeconnected.com](http://www.xtremeconnected.com)** for video tutorials, updated manuals and more FAQs for your device.

### **My device won't connect to my network!**

- 1.** Make sure you are connected to your **2.4 GHz network** and your device is blinking red before you start trying to connect your device.
- 2.** You may need to reset your device if you are having trouble. Check out page 2 for the location of your device's reset button.
- 3.** To allow the app to locate the network, you may need to allow permissions for location and turn on your Bluetooth.
- 4.** If you are not certain what type of network you have, contact your Internet Service Provider and ask them to create a separate, dedicated **2.4GHz network**. You can also do this manually in your router's settings.
- 5.** Try moving to a spot closer to your router for connecting.
- 6.** You can also purchase a WiFi extender to increase your WiFi range and strength.
- 7.** In some cases, you can try using the secondary pairing mode by clicking "EZ Mode" on the Add Device screen (see screenshot on bottom of page 3 for reference). Follow the on-screen instructions.