



CONNECTED HOME



Dimmable Warm White LED Bulb
MANUAL
XLB7-2001-SWT

GETTING STARTED

Thank you for choosing the **Xtreme™ Connected Home** Smart LED Bulb. This quick start guide will help you with setup and installation.

Package Includes:



- Smart Bulb
- Quick Start Guide

ESTIMATED SETUP



What You Need:



App



2.4GHz



5GHz



2.4GHz WiFi





Before setup, make sure your phone is connected to the 2.4GHz WiFi network that your device will be placed on. You may also need to turn on location and Bluetooth to find nearby networks.



CONNECT THE DEVICE

STEP 1

Download the free **Xtreme™ Connected Home** app from the AppStore (for iPhones) or Google Play Store (for Android phones).




STEP 2

Make sure your mobile device is connected to your **2.4GHz WiFi** network.

Open the app and **click** "Register" by following the on-screen instructions.

After your initial sign in, your app will remember your password and log you in automatically.


You can also choose to manually log out under Settings in the Main menu.



Click

Register

Log in with existing account



You may need to check your Spam folder for the verification code

STEP 3

Turn off power to the light socket. Screw the bulb into the light socket. Turn power back on.



NOTE: The bulb should start blinking rapidly (about 4 times per second) for EZ pairing mode.


To reset the bulb into pairing mode, turn the bulb off and back on 3-5 times

LED Behavior	Device Status
Flashing Rapidly	EZ Pairing
Flashing Slowly	AP Pairing

STEP 4

Make sure your Bluetooth® is enabled.

After logging in, **click** "+" on the top right of the screen and **select** "Add device".



Click




Select




The app will detect the WIFI+BLE enabled device and ask you if you want to **add it**



Make sure the check is marked next to the device you want to add, **click** the + button



Make sure your 2.4GHz network is selected, input the password and **press** confirm



NOTE: Once successful then go directly to Step 7.

If the app does not detect your device, skip this part and proceed to Step 5.

STEP 5

Select the Bulbs category and **confirm** that the indicator light is still rapidly blinking.

Click "Confirm indicator rapidly blink".



? **Help:** Switch between pairing modes. See troubleshooting page 11.




STEP 6

Confirm that the displayed **WiFi** network is your **2.4GHz WiFi** network, **enter** your WiFi password and **click** "Next".

Confirm WiFi



Enter and Click



 **Help:** If you need information about **2.4GHz WiFi** networks, click the link to go to our Connect FAQs on our website.



STEP 7

Your Smart LED Bulb will now be connected to the network. Confirm the settings for your device and then **Click** "Done".



TIP: You can put your Smart LED Bulb directly in a room by selecting one of the available rooms. **Click** the button to change the name of the product.

PROCESSING TIME



Your **Xtreme™ Connected Home** Smart LED Bulb is now ready to use. You can now set schedules, timers and control your Smart Plug remotely.

We hope you enjoy using your **Xtreme™ Connected Home** Smart LED Bulb. For frequently asked questions and instruction videos, please visit our website at www.xtremeconnected.com.

VOICE ACTIVATION

To enable voice access for your Smart LED Bulb, you will need to link the **Xtreme™ Connected Home** skill with your choice of voice assistant.

Voice Activation for Alexa


Make sure your Alexa device is installed and set up first.

STEP 1

Open your Alexa app.


STEP 2

Open the menu to search for “Skills”.



STEP 3

Search for & **choose** Xtreme Connected.



Choose

STEP 4

Authorize your account with the Alexa skill using the username and password from your **Xtreme™ Connected Home** app.

STEP 5

Using the name you assigned your Smart LED Bulb, you can ask Alexa to turn on/off your Smart LED Bulb.

Ex: “Alexa, change bedroom LED bulb to red”.

Voice Activation for the Google Assistant


Make sure your Google Assistant device is installed and set up first.

STEP 1

Open your Google Home app.

STEP 2

Click the "+" to add a new device.



Click

STEP 3


Click "Set up device".



Click

STEP 4


Click "Have something already set up?"



Click

STEP 5

Search for & choose Xtreme™ Connected Home.



Choose

STEP 6

Authorize your account with the Google Assistant skill using the username and password from your Xtreme™ Connected Home app.


STEP 7

Using the name you assigned your Smart LED Bulb, you can ask the Google Assistant to turn on/off your Smart LED Bulb. Ex: "Ok Google, change bedroom LED bulb to red".

Voice Activation for Siri


STEP 1

Open the Xtreme™ Connected Home app and click the “+” at the top right of the Home Screen and select “Add Scene”



STEP 2

Select “launch Tap To Run” and fill out the information.



STEP 3

Once your Smart Scene is created, return to the Smart Scene manager by clicking on the three lines in the top left of the Home Screen to open the main Menu, and then selecting “Smart Scenes”.



 Smart Scenes


STEP 4

Click the button at the bottom of the screen that says “Add to Siri”.



STEP 5

Select your new Tap to Run Smart Scene from the list and click “Add to Siri”.



STEP 6

Create a custom phrase for Siri to run your Smart Scene.
(this can be any verbal command)

Now Siri can use your voice and custom verbal command to turn your Smart LED Bulb on or off, adjust the device at the same time as your other smart devices, or whatever you've set up as your Tap To Run Smart Scene.

To see Warranty information and Certification Legal warnings, please see our website.

www.xtremeconnected.com

Message and Data rates may apply. If you have any questions about this product contact the manufacturer for support, do not return to retailer.

Referenced brands and trademarks are for compatibility listing only, not associated with this product. iPhone is a trademark of Apple INC., registered in the US and other countries.

App store is a service mark of Apple Inc. Google Play and Google Play logo are trademarks of Google Inc. © 2022 Google Inc. All rights reserved.

Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

FCC Compliance

This device complies with Part 15 of the FCC. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To satisfy FCC's RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation.

To ensure compliance, operations at closer than this distance is not recommended.

THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS. RISK OF ELECTRICAL SHOCK - USE IN DRY LOCATION ONLY. DO NOT USE WITH DIMMERS. NOT FOR USE IN TOTALLY ENCLOSED LUMINAIRES.

HAVING TROUBLE WITH SETUP?

Don't return this product to the retailer, we're here to help

Please call us at **855-999-8041** or visit **www.xtremeconnected.com** for video tutorials, updated manuals and more FAQs for your device.

My device won't connect to my network!

- 1.** Make sure you are connected to your **2.4 GHz network** and your device is blinking red before you start trying to connect your device.
- 2.** You may need to reset your device if you are having trouble. Check out page 2 for instructions.
- 3.** To allow the app to locate the network, you may need to allow permissions for location and turn on your Bluetooth.
- 4.** If you are not certain what type of network you have, contact your Internet Service Provider and ask them to create a separate, dedicated **2.4GHz network**. You can also do this manually in your router's settings.
- 5.** Try moving to a spot closer to your router for connecting.
- 6.** You can also purchase a WiFi extender to increase your WiFi range and strength.
- 7.** In some cases, you can try using the secondary pairing mode by clicking "EZ Mode" on the Add Device screen (see screenshot on bottom of page 4 for reference). Follow the on-screen instructions.

Jem Accessories, Inc. Limited Warranty Policy for Xtreme Connected Home.

Please read and understand all instructions before using this product.

If damage is caused by failure to follow the instructions, this warranty is null and void.

This limited warranty contains important information about your rights and obligations, as well as limitations and exclusions that may apply to you.

1. WHAT THIS LIMITED WARRANTY COVERS; PERIOD OF COVERAGE Jem Accessories, Inc. ("Jem Accessories"), 32 Brunswick Ave, Edison, New Jersey, USA, warrants to the owner of the enclosed Xtreme Connected Home-branded product contained in this box ("Product") will be free from defects in materials and workmanship for a period of one year. Notwithstanding the foregoing, the Warranty Period for a factory refurbished Product is one (1) year, even if installed by a professional. If the Product fails to conform to this Limited Warranty during the Warranty Period, Jem Accessories will, at its sole discretion, either (a) repair or replace any defective Product or component; with proof of purchase using original documentation. Repair or replacement may be made with a new or refurbished product or components, at Jem Accessories's sole discretion. If the Product or a component incorporated within it is no longer available, Jem Accessories may, at Jem Accessories's sole discretion, replace the Product with a similar product of similar function. This is your sole and exclusive remedy for breach of this Limited Warranty. Any Product that has either been repaired or replaced under this Limited Warranty will be covered by the terms of this Limited Warranty for the longer of (a) ninety (90) days from the date of delivery of the repaired Product or replacement Product, or (b) the remaining Warranty Period. This Limited Warranty is not transferable from the original purchaser to subsequent owners.

2. TOTAL SATISFACTION RETURN POLICY If you are the original purchaser of the Product and you are not satisfied with this Product for any reason, you may return it in its original condition to the retailer in compliance with the retailer's return policy.

3. WARRANTY CONDITIONS; HOW TO GET SERVICE IF YOU WANT TO CLAIM UNDER THIS LIMITED WARRANTY Before making a claim under this Limited Warranty, the owner of the Product must (a) visit www.xtremeconnected.com during the Warranty Period to provide notice of your warranty claim and describe the alleged failure, and (b) comply with Jem Accessories (or its authorized distributor's) return shipping instructions. Jem Accessories will have no warranty obligations with respect to a returned Product if it determines, at

its reasonable discretion after examination of the returned Product, that the Product is an Ineligible Product (defined below). Jem Accessories will bear all costs of return shipping to owner and will reimburse any shipping costs incurred by the owner, except with respect to any Ineligible Product or products shipped internationally, for which the owner will bear all shipping costs.

4. WHAT THIS LIMITED WARRANTY DOES NOT COVER This Limited Warranty does not cover the following (collectively "Ineligible Products"): (i) Products marked as "sample" or "Not for Sale", or sold "AS IS"; (ii) Products that have been subject to: (a) modifications, alterations, tampering, or improper maintenance or repairs; (b) handling, storage, installation, testing, or use not in accordance with any quick start guide, manual or other instructions provided by Jem Accessories; (c) abuse or misuse of the Product; (d) breakdowns, fluctuations, or interruptions in electric power or the telecommunications network; or (e) Acts of God, including but not limited to lightning, flood, tornado, earthquake, or hurricane; or (iii) any non-Jem Accessories branded hardware products, even if packaged or sold with Jem Accessories hardware. This Limited Warranty does not cover consumable parts, including batteries, unless damage is due to defects in materials or workmanship of the Product, or software (even if packaged or sold with the product). Jem Accessories recommends that you use only authorized service providers for maintenance or repair. Unauthorized use of the Product or software can impair the Product's performance and may invalidate this Limited Warranty.

5. DISCLAIMER OF WARRANTIES Except as stated above in this limited warranty, and to the maximum extent permitted by applicable law, Jem Accessories disclaims all express, implied, and statutory warranties and conditions with respect to the product, including the implied warranties of merchantability and fitness for a particular purpose. To the maximum extent permitted by applicable law, Jem Accessories also limits the duration of any applicable implied warranties or conditions to the duration of this limited warranty.

6. LIMITATION OF DAMAGES In addition to the above warranty disclaimers, in no event will Jem Accessories be liable for any consequential, incidental, exemplary, or special damages, including any damages for lost data or lost profits, arising from or relating to this limited warranty or the product, and Jem Accessories's total cumulative liability arising from or related to this limited warranty or the product will not exceed the amount actually paid for the product by the original purchaser.

7. LIMITATION OF LIABILITY The Jem Accessories online services at www.xtremeconnected.com ("services") provide you information ("product information") regarding your Jem Accessories products or other peripherals

connected to your products ("product peripherals"). The type of product peripherals that may be connected to your product may change from time to time. Without limiting the generality of the disclaimers above, all product information is provided for your convenience, "as is", and "as available". Jem Accessories does not represent, warrant, or guarantee that product information will be available, accurate, or reliable or that product information or use of the services or product will provide safety in your home. You use all product information, the services, and the product at your own discretion and risk. You will be solely responsible for (and Jem Accessories disclaims) any and all loss, liability, or damages, including to your wiring, fixtures, electricity, home, product, product peripherals, computer, mobile device, and all other items and pets in your home, resulting from your use of the product information, services, or product. Product information provided by the services is not intended as a substitute for direct means of obtaining the information. For example, a notification provided through the service is not intended as a substitute for audible and visible indications in the home and on the product, nor for a third party monitoring service that monitors alarm state.

8. YOUR RIGHTS AND THIS LIMITED WARRANTY This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Likewise, some of the limitations in this Limited Warranty may not apply in certain states, provinces or jurisdictions. The terms of this Limited Warranty will apply to the extent permitted by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisory service.

If you need to start a warranty claim for your Xtreme Connected Home device, please reach out to Customer Support by emailing customerservice@xtremecables.com or calling our support number 855-999-8041.

Please allow 7-10 business days to process warranty claims. Customers located outside of U.S. will be responsible for all shipping costs.

Last Updated: June 8, 2022